



**1 ENLARGED AREA**  
C2 1"=10'-0"




**2 ENLARGED AREA**  
C2 1"=10'-0"

- PLAN KEY NOTES:**
- ① REMOVE ALL TREES AND SHRUBS IN COURT YARD. GRIND STUMPS TO BELOW GRADE. REMOVE ALL ROOTS EXPOSED AT SURFACE. PROVIDE FILL SOIL TO FILL ALL DEPRESSIONS AND VOIDS CAUSED BY REMOVAL. PROVIDE NEW SOLID SLAB SOD AT ALL AREAS DISTURBED BY CONSTRUCTION.
  - ② RESTORE ROCK POND AREA TO ORIGINAL CONDITION AFTER INSTALLATION OF STORM SEWER & ROOF DRAIN.
  - ③ REMOVE & REPLACE SIDEWALK PAVING AS REQUIRED FOR INSTALLATION OF ROOF DRAIN STORM SEWER
  - ④ CONNECT TO EXISTING TRANSITE STORM SEWER. PROVIDE FERNCO OR SIMILAR ADAPTER COMPATIBLE WITH NEW AND EXISTING PIPING AND CONCRETE ENCASE. SEE DETAIL 12/C3
  - ⑤ CONTRACTOR SHALL TV ALL THE EXISTING STORM SEWER PIPING TO BE LEFT IN OPERATION TO DETERMINE THE CONDITION OF THE LINES IN PLACE. SUBMIT VIDEO IN DVD FORMAT TO ARCHITECT FOR REVIEW.
  - ⑥ REMOVE EXISTING BRIDGE & PLACE BACK AFTER CONSTRUCTION. REPAIR/REPLACE ANY DAMAGED AREAS TO RESTORE TO ORIGINAL CONDITION.
  - ⑦ PROVIDE DOWN SPOUT ADAPTER AND RISER. SEE DETAIL 13/C3.
  - ⑧ REMOVE AND REPLACE EXISTING SIDEWALK, SEE DETAILS SHT. C4.
  - ⑨ REMOVE EXISTING AREA INLET & REPLACE WITH NEW BASIN, SEE DETAIL 11/C3. VERIFY EXISTING FLOW LINES PRIOR TO CONSTRUCTION.
  - ⑩ GRADE COURTYARD AREA UNIFORMLY TOWARD AREA DRAINS (TYPICAL).



**3 ENLARGED AREA**  
C2 1"=10'-0"



DATE: 02/14/2012  
REV.:

C2  
OF 4